



The IHS crane scale offers a strong, safe solution for weighing heavy, suspended loads in industrial shipping and production operations. Ruggedly constructed, IHS features robust metal die-cast housing, a rotating plated steel hook and sturdy, oversized shackle. A remote control is included to allow scale operation from a safe distance. Readings are shown on a bright-red LED display, making them visible in any lighting conditions. The hold function retains the reading on the display after the weight is removed from the scale, allowing time for the operator to record the value.

When strength and safety are essential, IHS is the overwhelming winner to weigh suspended loads



Features

- Bright LED display for easy viewing in most environments
- Rotating hook allows easy access while loading, then safely locks in place during weighing
- Remote control allows safe, hands-free operation
- Sealed keypad protects against dirt and spills
- Solid metal housing resists spills and protects internal components
- Auto power-off to save energy
- Rechargeable battery included for operation almost anywhere
- AC adapter included

Applications

- Weighing

About ADAM:

For more than 40 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

Model	IHS 2a	IHS 6a	IHS 10a	IHS 20a
Capacity	2000lb / 1000kg	6000lb / 3000kg	10000lb / 5000kg	20000lb / 10000kg
Readability	0.5lb / 0.2kg	1lb / 0.5kg	2lb / 1kg	5lb / 2kg
Repeatability (S.D.)	0.5lb / 0.2kg	1lb / 0.5kg	2lb / 1kg	5lb / 2kg
Linearity (+/-)	1lb / 0.4kg	2lb / 1kg	4lb / 2kg	10lb / 4kg
Ultimate Overload Limit	3000lb / 1500kg	9000lb / 4500kg	15000lb / 7500kg	30000lb / 15000kg
Weighing Units	kg, lb			
Stabilization Time (sec)	3			
Calibration	External calibration			
Display	LED with 1.2"/ 30mm -high digits			
Power Supply	7.2VDC 2A adapter / Internal rechargeable battery			
Operating Temperature	0° to 40°C / 32° to 104°F			
Housing	Die-cast aluminum			
Overall Dim.	10.2"x8.4"x24.7" / 260x214x628mm (wxdxh)			
Net Weight	26.4lb / 12kg			
Overload Limit	Adam Equipment Co Ltd, its directors, staff, owners and affiliated companies and organizations cannot be held liable for any resulting damage or injury sustained as a result of the machines being used in excess of their capacities and ultimate overload limits.			

Accessories

Item number	Description
700660288.....	Calibration certificate

Supplied by