



SHS hanging scales offers a strong and safe solution for weighing suspended objects. Ruggedly constructed to perform dependably in industrial settings, the SHS features polycarbonate indicator housing, chrome-plated steel hook, safety catch and oversized swivel shackle and bolt. The hook and shackle rotate, giving complete flexibility. A remote control allows safe and simple operation of the scale. Readings are shown on a bright-red LED display, making them visible in any lighting conditions, including outdoors. The hold function retains the reading on the display after the weight is removed from the scale, allowing time for the operator to record results.

## Bringing strength and safety to the forefront of industrial settings



### Features

- Bright LED display for easy viewing in most environments
- Rotating hook allows easy access while loading, then safely locks in place during weighing
- Lightweight design simplifies transport and portability
- Rugged construction stands up to industrial use
- Remote control allows safe, hands-free operation
- External calibration allows for verification and adjustment with weights
- Hold function freezes the displayed weight, allowing time to elapse without losing the result
- Zero-tracking feature ensures display returns to zero reading
- Programmable auto power-off to save energy

### Applications

- Weighing

### About ADAM:

For more than 45 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

Model	SHS 100a	SHS 300a	SHS 600a
<b>Capacity</b>	100lb / 50kg	300lb / 150kg	600lb / 300kg
<b>Readability</b>	0.02lb / 0.01kg	0.05lb / 0.02kg	0.1lb / 0.05kg
<b>Repeatability (S.D.)</b>	0.02lb / 0.00001kg	0.05lb / 0.00002kg	0.1lb / 0.00005kg
<b>Linearity (+/-)</b>	0.04lb / 0.02kg	0.1lb / 0.05kg	0.2lb / 0.1kg
<b>Ultimate Overload Limit</b>	200lb / 75kg	600lb / 225kg	900lb / 450kg
<b>Weighing Units</b>	kg, lb		
<b>Stabilization Time (sec)</b>	2		
<b>Calibration</b>	External calibration		
<b>Display</b>	LED with 0.6" / 15mm -high digits		
<b>Power Supply</b>	AC adapter / 4 x AA batteries / Internal rechargeable battery		
<b>Operating Temperature</b>	0° to 40°C / 32° to 104°F		
<b>Housing</b>	Polycarbonate		
<b>Overall Dim.</b>	5.8"x2.6"x12.6" / 148x65x320mm (wxdxh)		
<b>Net Weight</b>	2.6lb / 1.2kg		
<b>Overload Limit</b>	Adam Equipment Co Ltd, its directors, staff, owners and affiliated companies and organizations cannot be held liable for any resulting damage or injury sustained as a result of the machines being used in excess of their capacities and ultimate overload limits.		

## Accessories

Item number	Description
700660290 .....	Calibration certificate

Supplied by